FLOOR PLANS

All drawings and dimensions are approximate. Drawings are not to scale and are subject to change without notice. The developer reserves the right to make revisions. The units are measured at typical floors in the building and columns may vary in size depending on the floor level. The furnishing and accessories shown are for representation only.

The availability, length and width of the balcony varies depending on which floor and which orientation the unit is located within the building. There will be slight differences in the internal areas between the same unit types depending on the shaft sizes that go through the units.

RESIDENCE COME

Basement 02



RESIDENCE COME

Basement 01



RESIDENCE COME

Ground Floor



RESIDENCE COME

1st floor (Offices)



RESIDENCE COME

2nd floor

STD 1B

RESIDENCE COME

3rd floor

1B 2B 3B



RESIDENCE COME

4th floor

STD 3B



RESIDENCE COME

Roof